


2FT EuroFit Banner Display

Product Parts

- 1 - Top Cornered Pole
- 2 - Vertical Shock Cord Pole (x2)
- 3 - Fabric Graphic
- 4 - Horizontal Middle Pole
- 5 - Base




Display Set-Up

Step 1

Begin by removing all parts from the carry case and place on a clean, flat surface.


Step 3

Attach both of the Vertical Shock-Corded Poles (2) into the ports on the Base (5).




Step 5

Attach the Top Cornered Pole (1) to the Vertical Shock-Corded Poles (3) as shown.




Step 2

Assemble the two Vertical Shock-Corded Poles (2) by placing the tapered end of one pole into the large end of the next while pressing the snap button as shown.



Step 4

Insert the ends of the Horizontal Middle Pole (4) into both sides of the Vertical Shock-Corded Poles (2) as shown.



Step 6

Slide Graphic (3) over the top of the display as shown.



Storage & Care

Place all product parts into Carry Case and store in a cool dry location. Recommended for indoor use only. Machine wash on gentle cycle using mild detergent. Tumble Dry No Heat. Do NOT dry clean, Do NOT Iron.